



FUNCTIONAL LEARNING DEMO


Getting Started with Edge Precision Time How to Sign-up for a New Service

ROSHAN KUMAR, Principal Product Manager

Hi, I'm **Roshan Kumar**, Product Manager for Edge Precision Time at Equinix. In this video I'm going to show you how to sign-up for a new Edge Precision Time service. But before signing up, please watch our other video about prerequisites and network planning and make sure you meet with all our requirements.

In order to sign-up, login to Edge Services Portal at <https://edgeservices.equinix.com> using your Equinix customer account's username and password.


Select Edge Precision Time Service from the products catalog. This will take you to Edge Precision Time's home page. Click on "BUY NOW".



EPT GETTING STARTED WITH EDGE PRECISION TIME



Select your country and billing account. This will take you to the Edge Precision Time Portal.



Choose a name for your service.


Select PTP or NTP for your Protocol.

Select the Service Tier that's appropriate for your needs. The PTP Standard service tier supports approximately 20 clients, and Enterprise up to 100. For NTP, Standard supports approximately 1000 NTP synchronizations per second, and Enterprise approximately 5000 synchronizations per second.

Select your ECX port from the dropdown list.

Choose the time master location for this service. You may notice that the widget at the top gives you the visual cues about your configuration.


EPT GETTING STARTED WITH EDGE PRECISION TIME



Please enter the IP addresses that you have chosen for the time masters. Enter the VLAN ID of the VLAN that connects your devices to the ECX Fabric. Enter the gateway IP address if you plan to route the time packets to multiple subnets in your network.

Please review and accept the order terms and product policy.

Click on the Preview button.




EPT GETTING STARTED WITH EDGE PRECISION TIME




Verify your order summary.

Upload your purchase order or PO if requested. If you are a PO exempt customer, you'll need to upload a PO exempt form.

Now submit your order and wait in the dashboard for one or two minutes.



The status will change to “provisioned”.



Now you should be able to ping the time master servers' IP addresses. You can go ahead and configure your PTP or NTP time clients to point to the IP addresses of the Edge Precision Time masters.

Thank you for watching the demo. Please visit docs.equinix.com and look for Edge Precision Time for more details.